


# Delco Remy Service Parts


Model 1117807



Ref No	Description	Part Number	Notation	Qty Reqd
00	NUT-LOCK	830288		
00	TRANSFORMER ASSY	1979131		
00	INSULATION	1894472		
01	HOUSING-RECTIFIER	1876762		
02	ROTOR ASSY	1968904		
03	STATOR ASSY	10497825		
04	FRAME-DE	1852726		
05	REGULATOR	1116433	SVC. BY COMPL. REPLCMNT	
06	DIODE TRIO	1876797		
07	RECTIFIER BRIDGE ASSY	1875645		
08	FIELD COIL & SUPPORT ASSY	1974630		
09	ROLLER BEARING	9436064		
10	RACE-ROLLER BEARING	9436063		
11	BALL BEARING ASSY	10472935		
12	CAPACITOR ASSY	10474443		
13	SERV PKG, TERMINAL	10497168		
14	RELAY TERMINAL	1971673		
15	SCREW	9427129		
17	CONNECTOR	10497824		
18	CONNECTOR	10497661		
21	RETAINER/DE BEARING	10497221		
22	FAN	10467133		
23	LOCK WASHER-TRANSFORMER TERM.	453435		

# Delco Remy Service Parts


Model 1117807



Ref No	Description	Part Number	Notation	Qty Reqd
24	LOCK WASHER-GROUND SCREW	STD HWD		
26	NUT ASSY	1851808		
27	NUT-SHAFT-DE	10484823		
28	NUT-TRANSFORMER TERM.	432230		
29	NUT ASSY	1851808		
30	SCREW ASSY	10497222		
31	SCREW ASSY	1846955		
33	SCREW	1968945		
34	SCREW ASSY	1846955		
35	SCREW ASSY	830335		
35	SCREW ASSY	830338		
36	SCREW ASSY	1894458		
36	SCREW ASSY	1976061		
37	SCREW ASSY	830741		
38	SCREW ASSY	1846957		
39	SCREW ASSY	830338		
41	WASHER	815540		
45	WASHER-PLAIN-RECT. BRIDGE ATTACH. S	807295		
48	WASHER-SHAFT NUT	10484823		
50	WASHER-PLAIN-TRANSFORMER RECT. BRID	1919042		
51	WASHER-INSULATI	1894704		
51	WASHER-PLAIN-TRANSFORMER TERM.	1919042		
53	THRU BOLT	1968991		

# Delco Remy Service Parts

Model 1117807



Ref No	Description	Part Number	Notation	Qty Reqd
56	BUSHING	1892765		
58	BUSHING	1944973		
59	BUSHING	1894463		
60	CAP	1970227		
61	CLIP-TERM. STATOR LEADS	1975304		
62	COLLAR (INSIDE)-SPACE-DE BRG.	10497218		
65	GROMMET	1876805		
66	HOUSING	830285		
68	PLUG-BEARING WELL	1876813		
69	RECTIFIER ASSY	1984638		
73	LEAD ASSY	1894712		